Ponnaiyar Sub Basin

Pungar (Upper Gundar) Sub Basin

Legend

- Tanks
- Drainage
- River
- Pudukottai (Villages)
- Trichy (Villages)
- Karur (Villages)

Anthanallur
Thiruverumbur
Manikandam
Thogamalai
Viralimalai
Kunnandarkovil
Vaiyampatti
Manapparai
Kadavur
Marungapuri
Umayavas

ALANTHUR
R.T.MALAI
PUTHUR
VADASERI
PULUTHERI
NAGANUR
KALLADAI
PILLUR
PATHIRIPATTY
Uttupatti
PORUNTHALUR
KOMANGALAM
KUMARAMANGALAM
KUNNATHOOR
MATHUR
Sugathankurichi
Kumarakkudi
KALIKUDI
MELAPACHAKUDI
TIRUCHIRAPALLI Dt
MATHIYANIPATTI
Sengalakkudi
MANDAIYUR
AVOOR
LAKSHMANAMPATTI
Poruvai
BODHATHAKUDI
KATHALOOR
MEBOOTHKUDI
VADUSAPPATTI
Akkamayakkanpatti
NEERPALANI
THONDAIMANALLUR
PERAMBALUR
ALANGUDI
NADUVATTI
KALAMAVOORPALANDAMPATTI
PALLATHURPATTI
VANATHIRAYANPATTI
NAMBAMPATTI
VIRALIMALAI
VELLIKUDI
Mullaiyur
SOORIYUR
VEMMANI
SEMBINATHAM
PALAVIDUTHI
MULLIPADI
KADAVUR
VIRUTHAPATTI
VIRALUR
THIRUNALUR
PAKKUDI
VILAPATTI
MARUTHAMPATTI
KATTAKUDIKOUNGUDIPATTI
NANGUPATTI
THENKAITHINNIPATTI
THENNAMPATTI
Thennangudi
IRUNTHIRAPATTI
ESWARRANKOIL
KOTHIRAPATTI
RAMOOSAL
VETTUKKADU
PUNGINIPATTI
Illuppur
RAVANOOR
THERAVUR
AGARAPATTI
Tattanji
Payur
ERNAI
KODUMBALUR
PERIYAMANU

Cauvery Delta Sub Basin

AGNIYAR BASIN

Amaravathi Sub Basin

Scale

0 1.75 3.5 7 10.5 14

Kilometers

78°10'0"E
78°20'0"E
78°30'0"E
78°40'0"E
78°50'0"E

10°50'0"N
10°40'0"N
10°30'0"N